

SECTION 7

SETTING TILE

After the Homax® SPRAY & SET™ Wall Tile Adhesive has cured, you can begin by setting your tiles.

- To set tiles, hold them at an angle to the surface, align one side with adjacent tiles and then tip the tile onto the glued surface.
- Do not slide or wiggle the tiles into place or the bond will not hold.
- Once properly aligned, press the tile firmly in the adhesive.
- Once the tile is placed, it should not move.
- If using irregular shaped tiles, stone, mosaics, mesh tile, or large format tiles, see Section 10 "Additional Applications".
- It is best to back butter tiles when spraying the wall to give those tiles a longer cure time and better adhesion.
- You only have to wait one hour after setting your tile to begin grouting.

Here's a helpful hint: To save time and make the project easier, spray the backs of tiles that will need back buttering when you are spraying your wall. That way they are ready to use when you need them. It is a good idea to back butter a few extra tiles on all jobs in case you need to reposition any tiles. Then, you will not have to wait to set those tiles. If you do not need them, you can use them as your last tiles and you have not wasted anything.



Tip the tile into place – do not slide or wiggle tiles.